

Maintenance Instructions –

Profiles Rubber Wall Base - Type TP BurkeBase Premium Rubber Wall Base - Type TS RubberMyte Rubber Wall Base - Type TP Mercer Vinyl Wall Base - Type TV

Burke Flooring Wall Base of any type, normally requires very little maintenance. Due to its refined and smooth surface, it maintains its natural luster with very little maintenance and requires very little attention.

Regular Cleaning:

For routine cleaning, wipe base with a damp cloth. This will usually be sufficient to restore the wall base finish an appearance. A spray on neutral cleaner, glass cleaner or countertop cleaner will normally do the job. Be careful not to overspray cleaner on painted walls or wall covering.

Scuff Removal:

Shoe sole marks, marks from cleaning equipment and other rolling stock can be unsightly and require removal. Most such marks can be removed with a mildly abrasive cleaner such as Soft Scrub. Abrasive cleaners like Comet are not recommended.

Wax Removal:

Waxing Burke Flooring Wall Base is not recommended. It is not required and it normally and adds to the overall maintenance cost of the product. Sometimes, the wall base is accidentally waxed as the adjacent tile flooring is waxed. If this is unsightly or unobjectionable, the wax can be removed. A gentle hand application of a neutral pH wax remover is most effective. Be careful not to over strip the wall base that could cause color variation that would be more noticeable than the discoloration of the wax.